



Drop Down Ladder Racks

Passenger Side Driver Side



Clamp & Lock Ladder Racks

Passenger Side Driver Side



Crossbar Racks

2 Bars 3rd Bar



Cargo Racks (5 Crossbars)

	Passenger Side	Driver Side	Passenger Side	Driver Side	2 Bars	3rd Bar	
GM							
CHEVY EXPRESS, GMC SAVANA	4092L*	40963	4082L*	4081L	40823	40824	40890*
*Required Mount Kit	409CD		408CC				4089C
40823 w/2 Retractable Ratchet Straps					40825		
FORD							
TRANSIT LOW ROOF	4092L*	40963	4082L*	4081L	40821*	40822	40890*
*Required Mount Kit	409TD		408TC		4A82T		4089T
40821 w/2 Retractable Ratchet Straps					40819		
TRANSIT MID/HIGH ROOF (* MID ROOF)	4099H*	40913					
*Required Mount Kit	409TD						
TRANSIT CONNECT (Mount Kit Included) 40821 w/2 Retractable Ratchet Straps	40933	40943	4080L	4081L	40821 40819	40822	80060
MERCEDES							
METRIS	4092L*	40963	4082L*	4081L	40821	40822	
*Required Mount Kit	4081M		4081M				
40821 w/2 Retractable Ratchet Straps					40819		
The 4092L, 4082L & 40821 racks will only fit 126" WB Metris vans							
SPRINTER STANDARD ROOF	4097M*	40983					40890*
*Required Mount Kit	4081S						4089T
SPRINTER HIGH ROOF	4099H*	40913					
*Required Mount Kit	4081S						
NISSAN							
NV LOW ROOF	4092L*	40963	4082L*	4081L	40821	40822	40890*
*Required Mount Kit	409ND		408NC				4089T
40821 w/2 Retractable Ratchet Straps					40819		
NV HIGH ROOF	4099H*	40913					
*Required Mount Kit	409ND						
NV200 (Mount Kit Included) 40821 w/2 Retractable Ratchet Straps	40933	40943	4080L	4081L	40821 40819	40822	80060
RAM							
PROMASTER LOW ROOF	4097M*	40983					40890*
*Required Mount Kit	4081P						4089P
PROMASTER HIGH ROOF	4099H*	40913					
*Required Mount Kit	4081P						
PROMASTER CITY (Mount Kit Included) 40821 w/2 Retractable Ratchet Straps	40933	40943	4080L	4081L	40821 40819	40822	80060



Drop Down Ladder Racks

Passenger Side Driver Side



Clamp & Lock Ladder Racks

Passenger Side Driver Side



Crossbar Racks

2 Bars 3rd Bar



Cargo Racks (5 Crossbars)

	Passenger Side	Driver Side	Passenger Side	Driver Side	2 Bars	3rd Bar	
GM							
CHEVY EXPRESS, GMC SAVANA	4A93L*	4A96L	4A82L*	4A81L			4089A*
Factory Preassembled Double Drop Down Rack	4A95L*						
*Required Mount Kit	409CD		408CC				4089C
FORD							
TRANSIT LOW ROOF	4A93L*	4A96L	4A82L*	4A81L	4A821*	4A822	4089A*
Factory Preassembled Double Drop Down Rack	4A95L*						
*Required Mount Kit	409TD		408TC		4A82T		4089T
TRANSIT MID/HIGH ROOF (1 MID ROOF)	4A99H*	4A91H					
*Required Mount Kit	409TD						
TRANSIT CONNECT (Mount Kit Included)	4A97L	4A98L	4A80L	4A81L	4A821	4A822	8006A
MERCEDES							
METRIS	4A97L	4A98L	4A80L	4A81L	4A821	4A822	
SPRINTER STANDARD ROOF	4A93M*	4A96M					4089A*
*Required Mount Kit	4081S						4089T
SPRINTER HIGH ROOF	4A99H*	4A91H					
*Required Mount Kit	4081S						
NISSAN							
NV LOW ROOF	4A93L*	4A96L	4A82L*	4A81L	4A821	4A822	4089A*
Factory Preassembled-Assembled Double Drop Down Rack	4A95L*						
*Required Mount Kit	409ND		408NC				4089T
NV HIGH ROOF	4A99H*	4A91H					
*Required Mount Kit	409ND						
NV200 (Mount Kit Included)	4A97L	4A98L	4A80L	4A81L	4A821	4A822	8006A
PROMASTER STANDARD ROOF							
Factory Preassembled-Assembled Double Drop Down Rack	4A93M*	4A96M					4089A*
*Required Mount Kit	4081P						4089P
PROMASTER HIGH ROOF	4A99H*	4A91H					
*Required Mount Kit	4081P						
PROMASTER CITY (Mount Kit Included)	4A97L	4A98L	4A80L	4A81L	4A821	4A822	8006A

For detailed product information and accessories visit: kargomaster.com

v3.18 121819